

# Coin Purse with covered zipper ends



Finished size: 5" x 3"




## You need:

- Fabric for front, back and tabs of coin purse;  
2 pieces - 3 ½" x 6" (9 cm x 15cm),  
2 pieces - 2" x 1 ½" (5 cm x 3.5 cm)
  - Fabric for lining;  
2 pieces - 3 ½" x 6" (9 cm x 15cm)
  - Zipper: at least 5" (12 cm)
  - Iron on woven interfacing, (optional);  
2 pieces - 3 ½" x 6" (9 cm x 15cm)
- Sewing Machine with zipper foot
  - Cutting Mat, Ruler and Rotary Cutter
  - General Sewing Supplies

All seam allowances are ¼" (6mm) unless otherwise stated.



If zipper is longer than 5" it has to be shortened. Mark finished length (5" or 12 cm) on zipper and tack zipper with a few stitches just inside markings. Make sure zipper pull is in between markings. Cut zipper on markings.




Fold tabs in half so short ends meet, press and unfold. Fold edges towards crease, press and refold first fold.



Enclose ends of zipper with tabs and stitch them in place. Cut the edges of the tabs even with the zipper.

Iron on the interfacing (if using) on the back and front of the outer fabric.



Mark the centre of zipper and top edges of main fabric and lining pieces. Place zipper right side down along the top of the right side of the front or back piece. Place one lining piece right side down so the zipper is sandwiched between the fabric pieces. Make sure all the centre markings line up. Stitch with a zipper foot. Move zipper pull out of the way as needed.



Fold both fabric pieces away from the zipper and press. Repeat for other side of zipper



The coin purse should look like this now.

Topstitch the seams if you wish.



Open zipper  $\frac{3}{4}$  of the way. Pin main fabric pieces right sides together and lining pieces right sides together. The zipper seam allowances should be folded towards the main fabric. Stitch all the way around, leaving a 2" opening in the bottom of the lining. Use a zipper foot and avoid catching the zipper ends in the seam.



Turn the right way through the opening and close the seam in bottom of lining, either by hand or machine. Push lining inside the coin purse.



Enjoy your coin purse!